


TENERGY®

Item No. 02460

Works with



Battery Charger For Tenergy Li-ion RCR123A 650/750mAh Rechargeable Batteries

Please carefully read the instructions before use.

INSTRUCTION MANUAL

EN

CAUTION -----

- DO NOT charge non-rechargeable batteries.
- Keep this charger out of reach of children younger than 8 and individuals who require supervision. This device can present an electrical hazard and should not be treated as a toy or handled without adult supervision.
- This device is only to be used with the USB to Micro USB cable provided.
- During charging, batteries must be placed in a well-ventilated and clean area.

WARNING -----

- The charger is only compatible with Tenergy 3.7V 650/750mAh Li-ion RCR123A rechargeable batteries.
- **DO NOT CHARGE ANY TYPES OF NON-RECHARGEABLE LITHIUM CR123A/CR123 BATTERIES, OR ANY OTHER TYPES OF NON-RECHARGEABLE BATTERIES. CHARGING NON-RECHARGEABLE BATTERIES WILL CAUSE FIRE OR EXPLOSIONS.**
- DO NOT charge any other types of battery. Only charge Tenergy lithium-ion RCR123A Batteries. Recharging any other battery may cause explosion or charger failure.
- DO NOT disassemble the charger.
- The charger is only intended for indoor usage and should be kept away from high temperature or wet areas.
- Keep charger dry and away from liquids. The charger may fail in extreme humidity or if exposed to water.
- Keep the charger and batteries out of reach of children.
- DO NOT use the charger if it is damaged.
- Charger might not be able to fully charge batteries which have not been in use for a long period of time. Several charging and discharging will improve battery performance.

Features -----

- Charger designed and certified to work with Tenergy 3.7V 650/750mAh RCR123A rechargeable batteries for Arlo Wire-free Security Cameras (VMC3030).
- USB power adapter input.
- Charges up to four batteries independently with individual detection for each.
- Detailed LCD display shows charging status.
- Constant current and constant voltage charging mode.
- High charging efficiency and charging speed.
- Save money and reduce waste by using rechargeable batteries.
- Charger is tested and certified by CE and FCC standards.

Operating Instructions -----


1. Insert 1 to 4 compatible Tenergy 3.7V rechargeable Li-ion batteries into the slots.
2. Ensure correct alignment matching the positive (+) and negative (-) polarity symbols marked inside the battery compartment.
3. Connect the charger to a stable USB power source using the included Micro-USB to USB cable.
4. Monitor the LCD screen for individual channel progress. When a channel reads "FUL", that specific battery is fully charged and ready for use.

NOTE: Actual charging time varies dependind on your USB power source, refer to the Estimated Time Chart.

LCD Indicator	Status
FUL	Fully charged
AVL	Empty slot
Er-1	Reverse polarity or short-circuit detected *
Er-2	Non-rechargeable battery detected **

*Check that batteries are inserted with correct polarity, matching the + and – symbols in each slot. Remove and reinsert. If Er1 persists, replace with a known-good RCR123A battery.

**Remove battery immediately. Do not attempt to charge non-rechargeable batteries.



Estimated Charging Time

(For Rechargeable RCR123A Capacity 650-750mAh)

5V 1A USB Power Adapter	3.8~4.5hrs
5V 2A USB Power Adapter	2.2~2.5hrs
USB Port 2.0 *	7.5~8.5hrs
USB Port 3.1 *	3.8~4.5hrs

*NOTE: Please refer to your computer's hardware specification.

Specification -----

- Input: USB DC 5V  500 - 2000mA
- Output: 4.2V  4 x 400mA (Max)
- Applicable battery type: Tenergy 3.7V 750mAh / 3.7V 650mAh rechargeable Li-ion battery

Only Use With -----

Tenergy 3.7V 750mAh
RCR123A Rechargeable
Li-ion battery
(Item No. 34253)



For additional questions, contact us at service@tenergy.com

Designed and Distributed by

Tenergy Corporation

436 Kato Terrace, Fremont, CA 94539, USA

Tel: (510) 979-9969, Fax: (510) 687-0328

<https://power.tenergy.com>

Manufactured by

Shenzhen Ryder Electronics Co.,Ltd Bldg C ,

Huaming industrial park, Huaming road, Dalang,Longhua,
Shenzhen, Guangdong China



A black rectangular icon representing a battery. Inside the rectangle, the word "Rechargeable" is written vertically in white, and "RCR123A" is written horizontally in white below it.

Rechargeable
RCR123A


Note: Charge your battery before use

To ensure the safety of lithium batteries during shipping, Tenenergy rechargeable RCR123A batteries are not shipped precharged. Please fully recharge with this charger before first use.

TENERGY®

Article No. 02460

Works with



Chargeur de Batterie pour Tenergy Li-ion RCR123A 650/750mAh Batteries rechargeables

Veuillez lire attentivement le manuel avant utilisation.

MANUEL D'UTILISATION

FR

MISE EN GARDE -----

- NE PAS charger des piles non rechargeables.
- Garder hors de portée des enfants (<8 ans) et personnes à surveiller. Risque d'électrocution : ceci n'est pas un jouet. Surveillance d'un adulte requise.
- Cet appareil doit uniquement être utilisé avec le câble USB vers Micro-USB fourni.
- Lors de la charge, les batteries doivent être placées dans un endroit propre et bien-ventilé.

AVERTISSEMENT -----

- Le chargeur est uniquement compatible avec les batteries rechargeables Li-ion RCR123A Tenergy 3,7V 650/750mAh.
- **NE CHARGER AUCUN TYPE DE PILES AU LITHIUM NON RECHARGEABLES CR123A/CR123, NI AUCUN AUTRE TYPE DE PILES NON RECHARGEABLES. LE CHARGEMENT DE PILES NON RECHARGEABLES PROVOQUERA UN INCENDIE OU DES EXPLOSIONS.**
- NE PAS charger d'autres types de batteries. Charger uniquement les batteries Li-ion RCR123A Tenergy. Le rechargement de toute autre batterie peut provoquer une explosion ou une défaillance du chargeur.
- NE PAS démonter le chargeur.
- Le chargeur est destiné uniquement à une utilisation en intérieur et doit être tenu à l'écart des températures élevées ou des zones humides.
- Garder le chargeur sec et à l'écart des liquides. Le chargeur peut tomber en panne en cas d'humidité extrême ou s'il est exposé à l'eau.
- Garder le chargeur et les batteries hors de portée des enfants.
- NE PAS utiliser le chargeur s'il est endommagé.
- Le chargeur pourrait ne pas être en mesure de charger

complètement des batteries qui n'ont pas été utilisées pendant une longue période. Plusieurs cycles de charge et de décharge amélioreront les performances de la batterie.

Caractéristiques - - - - -

- Chargeur conçu et certifié pour fonctionner avec les batteries rechargeables Tenergy 3.7V 650/750mAh RCR123A pour le caméras de sécurité sans fil Arlo (VMC3030).
- Tension mondiale pour l'entrée 100-240V AC.
- Quatre canaux indépendants pour le chargement et la détection de la batterie individuelle.
- L'affichage LCD détaillé montre l'état de charge.
- Mode de charge à courant constant et à tension constante.
- Haute efficacité de charge et vitesse de chargement.
- Économisez de l'argent et réduisez les déchets en utilisant des piles rechargeables.
- Le chargeur est testé et certifié selon les normes CE et FCC.

Instructions d'Opération - - - - -

1. Insérez 1 à 4 piles rechargeables Li-ion Tenergy de 3,7V compatibles dans les emplacements.
2. Assurez-vous d'aligner correctement les piles en faisant correspondre les symboles de polarité positive (+) et négative (-) indiqués à l'intérieur du compartiment des piles.
3. Connectez le chargeur à une source d'alimentation USB stable à l'aide du câble Micro-USB vers USB inclus.
4. Surveillez l'écran LCD pour suivre la progression de chaque canal. Lorsqu'un canal affiche "FUL", cela signifie que la pile correspondante est entièrement chargée et prête à l'emploi.

REMARQUE : Temps de charge variable selon l'USB. Voir tableau des estimations.

Témoin LCD	État
FUL	Complètement chargé
NUL	Espace vide
Er-1	Polarité inversée ou court-circuit détecté *
Er-2	Batterie non rechargeable détectée **

*Vérifiez que les piles sont insérées en respectant la polarité, de manière à faire correspondre les symboles + et – dans chaque compartiment. Retirez-les et réinsérez-les. Si le code Er1 persiste, remplacez-les par une pile RCR123A neuve ou en bon état de fonctionnement.

**Retirez la pile immédiatement. Ne tentez pas de charger des piles non-rechargeables.



MICRO USB PORT



Temps de charge estimé

(Pour RCR123A rechargeables d'une capacité de 650-750mAh)

5V 1A USB Power Adapter	3.8~4.5hrs
5V 2A USB Power Adapter	2.2~2.5hrs
USB Port 2.0 *	7.5~8.5hrs
USB Port 3.1 *	3.8~4.5hrs

*REMARQUE : Veuillez vous référer aux spécifications matérielles de votre ordinateur.

Caractéristiques -----

- Entrée: USB DC 5V  500 - 2000mA
- Sortie: 4.2V  4 x 400mA (Max)
- Type de batterie approprié: Batterie Li-ion rechargeable Tenergy 3.7V 750mAh / 3.7V 650mAh

N'utiliser qu'avec -----

Batterie Li-ion
rechargeable Tenergy
3.7V 750mAh RCR123A
(Article No. 34253)



Pour toute question supplémentaire, contactez-nous à service@tenergy.com

Conçu et distribué par
Tenergy Corporation
436 Kato Terrace, Fremont, CA 94539, USA
Tel: (510) 979-9969, Fax: (510) 687-0328

<https://power.tenergy.com>

Fabriqué par
Shenzhen Ryder Electronics Co.,Ltd Bldg C ,
Huaming industrial park, Huaming road, Dalang,Longhua,
Shenzhen, Guangdong China





Rechargeable
RCR123A

Remarque: Chargez votre batterie avant utilisation

Pour assurer la sécurité des piles au lithium lors de l'expédition, les piles rechargeables Tenenergy RCR123A ne sont pas expédiées préchargées. Veuillez recharger complètement avec ce chargeur avant la première utilisation.