

SFS WATERING GUN INSTRUCTIONS

*****VERY IMPORTANT****** When gun is to be used for the first time after purchase, please spray into a bucket or sink while gently shaking for 5 seconds. This removes any air from the gun and makes the gun ready to use. If this is not done the gun will reset slowly for the first few cell fills.

Please read these comments before use and most important of all, be sure to wear proper Safety equipment when servicing batteries!!

SETTING THE DEPTH STOP (Check your battery literature for actual recommended fill levels)

1. The front nozzle of your gun has a rubber disc and two o-rings on it. Slide these o-rings back toward the handle so they are about 2.5" from the exit end of the pipe.
2. On a battery, open the flip cap (or remove the quarter turn vent cap) and insert the gun until the tip of the gun touches the plate cover inside the battery cell.
3. Move the gun tip backwards, away from the plate cover about 1/2"
4. While holding the gun in this position slide the rubber disc and o-rings forward until they touch the flip cap (or the cell top). The depth stop is now set for the style of battery.

USING THE WATERING GUN

1. Screw the white nozzle onto the threaded end of the handle.
2. Attach the female ended quick connect to a hose yielding a minimum of 15 psi of flowing water pressure.
3. Attach the male end of the quick connect into the female end of the quick connect until it clicks.
4. Insert the tip of the gun into the battery until the depth stop contacts the flip cap (or cell top) For best results , keep the tip of the gun perpendicular to the battery cell.
5. Fully squeeze the handle. **DO NOT PARTIALLY SQUEEZE THE HANDLE AS THIS WILL PREVENT THE GUN FROM BEING ABLE TO SHUT OFF.**
6. As water touches the tip of the gun, you will feel and hear the flow stop.
7. **AS SOON AS FLOW STOPS, PLEASE RELEASE THE HANDLE!!! A TRICKLE OF WATER WILL CONTINUE TO FLOW UNTIL THE HANDLE IS RELEASED!!!**
8. A slight tap on the edge of the vent opening will remove any water droplets from the tip of the gun.
9. Move to the next cell and repeat the process.

LIQUID PRECISION, INC
P.O BOX 555
NEWFOUNDLAND, PA 18445

TEL. (570) 676-3869
FAX (866)-602-3410